Product 511327

511327 Passive holder with tilt swivel

When keeping your Galaxy S II Skyrocket in a passive holder, it is always within easy reach. A portable handsfree or a charging cable can be connected to the device when it is in the holder. The holder is attached onto a tilt swivel and can be adjusted in order to avoid light reflection. Attach onto a ProClip Mounting Platform.

EAN: 7320285113275

Item no 511327 fits:
Samsung Galaxy S II LTE i9210
Samsung Galaxy S II Skyrocket SGH-I727

INSTALLATION INSTRUCTIONS

1.

2.

3.

4.

Please read all of the instructions and look at the pictures before attaching the holder.

1. Loosen the screw in the center of the holder so you can remove the tilt swivel attaching plate on the back.

2. Place the attaching plate onto the desired position. Screw the attaching plate into place with the enclosed screws.

3. Place the holder over the attaching plate so the screw fits in the hole in the tilt swivel. Screw a few turns on the screw, just so the thread starts to pull. Pull the holder toward you and hold it slightly tensed, in the same time tighten the screw so the holder is pulled toward the tilt swivel. Tighten the screw firm at first, then loosen it a bit so the holder is firmly in place, but still can be adjusted.

4. The holder is in place.